



3327 Jaffa Dr. Sarasota, FL 34239 USA- Phone 941-955-1020 / 1-877-Whenever (943-6383)  
[www.SatellitePhoneStore.com](http://www.SatellitePhoneStore.com)

---

## **IRIDIUM Voicemail instructions for the Motorola Series Handset**

### **II. Forwarding your ISU (phone) to voice mail:**

1. Press Menu
2. Toggle (using <> button) to Messages (press OK)
3. Toggle (using <> button) to Message Settings (press OK)
4. Select Voicemail Number
5. Enter Voicemail Number 00881662990000. After pressing OK you will see Completed on the screen. Press C to return to the main Iridium Screen.
6. Press Menu
7. Toggle (using <> button) to Call Related features (press OK)
8. Toggle (using <> button) to Call Forwarding (press OK)
9. Select View Options (press OK)
10. Select View Options (press OK)
11. If ON, press OK. If OFF, toggle (using <> button) to On, press OK
12. Phone will then prompt you where you want your calls forwarded. In this case, select voice mail (press OK). Message will appear confirming that call forwarding is on.

### **II. To access your voice mailbox dial: 00881662990000**

1. Enter the phone number of the phone you are trying to get message for.
2. During the greeting press star ( \* ) key.
3. You will then be asked for a password = LAST SEVEN DIGITS of unit's phone number.

\*\*\*\*\***DO NOT CHANGE**\*\*\*\*\*

4. Press 1 to listen to your messages